

STRATAFLEX | REATEC Primer Guide

Substrate/Process	Pre-Treatment	Sealer	Putty Treatment	Sanding	Surface Cleaning	UK Primers
Plasterboard	Nail head/step difference treatment		SELECT (Topcoat)/ACE (Base coat)	#180-240 Sandpaper	Alcohol	Murabond Primer
Calcium Silicate Board	Nail head/step difference treatment	Sealer S	SELECT (Topcoat)/ACE (Base coat)	#180-240 Sandpaper	Alcohol	Murabond Primer
Mortar	Trowel finish, dry condition check	Sealer S	SELECT (Topcoat)/ACE (Base coat)	#180-240 Sandpaper	Alcohol	Murabond Primer
Baked Steel Sheet	Remove oil and grease		Polyester putty	#180-240 Sandpaper	Alcohol	Upol S2003/1
Electro-galvanized Steel Sheet	Remove oil and grease		Polyester putty	#180-240 Sandpaper	Alcohol	Upol S2003/1
Aluminium Plate	Remove rust/oil and grease		Polyester putty	#180-240 Sandpaper	Alcohol	Upol S2003/1
Stainless Steel Plate	Remove rust/oil and grease		Polyester putty	#180-240 Sandpaper	Alcohol	Upol S2003/1
Glass					Alcohol	Upol S2003/1
Shine Plywood, Lauan Plywood	Nail head/step difference treatment	SA Sealer	SELECT (Topcoat)/ACE (Base coat)	#180-240 Sandpaper	Alcohol	Murabond Primer
MDF	Nail head/step difference treatment	SA Sealer	Polyester putty	#180-240 Sandpaper	Alcohol	Murabond Primer
PVC Coated Steel Sheet	Condition check		Polyester putty	#180-240 Sandpaper	Alcohol	Upol S2003/1
Melamine Decorative Board,						Upol S2003/1
Polyester Decorative Plywood						

*Use alcohol to clean the finished surface if needed.

** Murabond primer to be diluted 2 parts water to 1 part primer.